



# FIX INSTANTANEO

Technical Data  
Revision  
06/2019



## DESCRIPTION:

Instant colorless cyanoacrylate adhesive.

## APPLICATIONS:

This is an adhesive suitable for non-porous surfaces, metal, rubber, plastics, (except polyethylene, polypropylene and Teflon), glass, porcelain, etc.

Ideal for quick, awkward jobs, it is very useful in the automotive industry, electronics, optics, jewelry, etc.

## PROPERTIES:

The joints obtained are invisible and highly resistant to traction (depending on the materials, the adhesive can resist up to 350 kg/cm<sup>2</sup>). Ideal for joints where it is difficult to hold the parts together.

## INSTRUCTIONS:

The surfaces to be joined must be clean, dry and free of dust and grease.

Remove any oxides or strippers. If necessary the surfaces may be cleaned with alcohol or acetone, or even sanded.

Check that the pieces to be joined fit snugly, then use the spout to spread the adhesive on one of them, avoiding contact with the fingers.

Join and press together for 10 – 15 seconds or until the bond is felt to become firm.

## STORAGE:

3 g. tubes: 18 months in original, sealed container.

8 g. bottles: 12 months in original and sealed container.

To assure good conditions of the product; it is recommended to store upright in a cool, dry place at approximately 5 °C.

Before using, keep the adhesive at normal temperature.

## TECHNICAL FEATURES

Appearance:	Colorless liquid, medium/low viscosity
Viscosity:	60 - 120 mPa.s
Resistance to handling:	5-10 seconds
Final resistance:	24 hours

## YIELD:

One drop sticks an area of 4 to 8 cm<sup>2</sup>, so more than 40 applications are obtained from 1 gram of adhesive.

## PRESENTATION:

Tube/Blister, 3g.

Bottle with brush/blister, 8g.

## HEALTH & SAFETY:

This product contains cyanoacrylate. Avoid skin and eye contact. Bonds skin in seconds. In case of skin contact wash thoroughly with soap and water; for separation use a blunt object (e.g. a teaspoon handle). In case of eye contact, keep eyes open, flush with water for 15 minutes and get medical attention.

*For further information, please request the product Safety Data Sheet.*

"The information contained herein is offered in good faith based on Selena's research and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information shall not be used in substitution for customer's tests to ensure that Selena's products are fully satisfactory for your specific applications. Selena's sole warranty is that the product will meet its current sales specifications. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. Selena FM S.A. specifically disclaims any other expressed or implied warranty of fitness for a particular purpose or merchantability. Selena disclaims liability for any incidental or consequential damages. Suggestions of use shall not be taken as inducements to infringe any patent. Technical indications and data appearing in this brochure are based on our current knowledge and experience and we decline all responsibility for consequences derived from inadequate use. Therefore, our guarantee is limited exclusively to the quality of the product supplied. This technical information can be modified without notice. If necessary request it periodically."



Quilosa - Selena Iberia S.L.U.

Centro empresarial Rivas Futura, C/ Marie Curie 19, Planta 6.1, 28521 Rivas, Madrid, Spain,  
Tel: +34 902 02 18 02 – Fax: +34 914 999 796, [info@quilosa.es](mailto:info@quilosa.es), [www.quilosa.com](http://www.quilosa.com)